Oil-Only DrumTop Pads #BTOP - 22", 25 pads/package



Eliminate messy drum tops with these Sorbent Oil-Only DrumTop Pads.

- Absorb drips from leaking pumps and help keep drum storage areas looking good
- Pre-cut bung holes make for easy access to drum
- Pads can be removed and replaced with pumps and valves installed
- Made from top-quality FineFiber Mat
- Color-coding helps you visually identify the right sorbent for your needs. Blue designates Oil-Only sorbency for oil and other petroleum-based fluids — but not water; fits into many professional surroundings.

BTOP Specifications

Dimensions:	ext. dia. 22"
Shipping Dimensions:	23" W x 23" L x 4" H
Sold as:	25 pads per package
Color:	Blue
Composition:	Polypropylene
Absorbency:	Up to 8.6 gal. per package
Absorbency per:	Up to 44 oz. per pad
Weight:	7 lbs.
# per Pallet:	72
Basis Weight:	HeavyWeight
Incinerable:	Yes
Ship Class:	175

Metric Equivalent Specifications

Dimensions:	ext. dia. 55.9cm
Shipping Dimensions:	58.4cm W x 58.4cm L x 10.2cm H
Absorbency:	Up to 32.6 L per package
Absorbency per:	Up to 1.3 L per pad
Weight:	3.2 kg

Online: **spilltech.com**

Phone: **1-800-228-3877 (N.Am.)** **1-770-475-3877 (Other)**

Fax: **1-800-872-3764 (N.Am.)** **1-770-410-1812 (Other)**

Email: **sales@spilltech.com**

6455 East Johns Crossing, Suite 375 • Johns Creek GA 30097

© 2023 SpillTech Environmental Corporation. All rights reserved.

BTOP Technical Information

Warnings & Restrictions:
There are no known warnings and restrictions for this product.

Regulations and Compliance:
29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

Technical Documents:
(Available at **spilltech.com**)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)

© 2023 SpillTech Environmental Corporation. All rights reserved.