Oil-Only 65-Gallon Kit Refill #RSPKO-65 - Absorbs up to 43.8 Gallons



Refill your SpillTech® Oil-Only 65-Gallon Spill Kit to ensure fast response.

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com

6455 East Johns Crossing, Suite 375 • Johns Creek GA 30097

© 2023 SpillTech Environmental Corporation. All rights reserved.

RSPKO-65 Specifications

Dimensions:	18" W x 24" L x 22" H
Sold as:	2 per package
Absorbency:	Up to 43.8 gal. per package
Weight:	42.36 lbs.
# per Pallet:	12
Incinerable:	Yes
Ship Class:	175
Includes:	40 - 15" x 19" White Oil-Only HeavyWeight SonicBonded Pads (WPB100H) 10 - 3" x 4' White Oil-Only Sorbent Socks (WSO430) 6 - 3" x 8' White Oil-Only Sorbent Socks (WSO815) 6 - 18" x 18" White Oil-Only Sorbent Pillows (WPIL1818) 2 - Pair Nitrile Gloves (A-GLV-NIT) 3 - 30" x 6" x 60" Yellow Disposal Bags & Ties (A-DISPBAG) 1 - 3" x 5" Vinyl Spill Kit Label (A-KITLABEL) 1 - Safety Goggles (A-GOG) 6 - 6" X 2" TamperProof Seals (A-SEAL)

Metric Equivalent Specifications

Dimensions:	46cm W x 61cm L x 56cm H
Absorbency:	Up to 165.8 L per package
Weight:	19.2 kg

© 2023 SpillTech Environmental Corporation. All rights reserved.

RSPKO-65 Technical Information

Warnings & Restrictions:
There are no known warnings and restrictions for this product.

Regulations and Compliance:
49 CFR 173.3(c)(1) - If a container of hazardous waste is damaged or leaking, it can be placed in a compatible salvage drum that meets UN criteria for shipping

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation…so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

33 CFR 154.1047(c)(2) - Concerning navigation and navigable waters, a facility which handles, stores or transports Group V petroleum oils must identify response plan resources such as containment booms and other methods.

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

Technical Documents:
(Available at **spilltech.com**)

Product Data Sheet (PDS)

© 2023 SpillTech Environmental Corporation. All rights reserved.